TX.EE SERIES RANGE



PLAN VIEW



SIDE VIEW



FRONT VIEW

Tower Model	Nominal Tonnage	Motor kW	Fan diameter (mm)	Overall Dimension (mm)					Piping Size				
				L	W	H	h	Air Inlet Height K	Water Inlet	Water Outlet	Overflow	Drain	Make Up Auto & Manual
TXS 1110D-450	334	11	3050	3430	6470	3620	920	2850	150	250	80	50	50
TXS 1110E-500	372	15							150	250	80	50	50
TXS 1110G-550	425	22							200	300	100	50	50
TXS 1110H-600	471	30							200	300	100	50	50
TXS 1210D-500	358	11	3350	3626	6830	3620	920	2850	150	250	80	50	50
TXS 1210E-550	398	15							200	300	100	50	50
TXS 1210G-600	454	22							200	300	100	50	50
TXS 1210H-650	504	30							200	300	100	50	50
TXS 1210I-700	541	37							200	300	100	50	50

Notes: 1. One nominal tonnage represents a 3GPM (0.684 m3/hr) of water from a 95°F (35°C) to 85°F (29.4°C) at a 78°F (25.6°C) entering wet-bulb temperature.

2. If you need multi-cell towers, consult your local Truwater representative.

TX.EE SERIES RANGE



PLAN VIEW



SIDE VIEW



FRONT VIEW

Tower Model	Nominal Tonnage	Motor	Fan diameter	Overall Dimension (mm)					Piping Dimension (mm)				
		kW	(mm)	L	W	H	h	Air Inlet Height K	Water Inlet	Water Outlet	Overflow	Drain	Make Up Auto & Manual
TXS 1114E-600	445	15	3050	3430	6470	4840	920	4070	200	300	100	50	50
TXS 1114F-650	479	18.5							200	300	100	50	50
TXS 1114H-750	574	30							200	300	100	50	50
TXS 1114I-800	615	37							200	300	100	50	50
TXS 1314F-750	574	18.5	3660	4075	6830	4840	920	4070	200	300	100	50	50
TXS 1314G-800	607	22							200	300	100	50	50
TXS 1314H-850	675	30							200	300	100	50	50
TXS 1314I-950	725	37							200	350	100	50	50
TXS 1314J-1000	779	45							200	350	100	50	50
TXS 1314K-1100	830	55							200	350	100	50	50

Notes: 1. One nominal tonnage represents a 3GPM (0.684 m3/hr) of water from a 95°F (35°C) to 85°F (29.4°C) at a 78°F (25.6°C) entering wet-bulb temperature.

2. If you need multi-cell towers, consult your local Truwater representative.

TX.EE SERIES RANGE



PLAN VIEW



SIDE VIEW



FRONT VIEW

Tower Model	Nominal Tonnage	Motor kW	Fan diameter (mm)	Overall Dimension (mm) L	W	H	h	Air Inlet Height K	Piping Dimension (mm) Water Inlet	Water Outlet	Overflow	Drain	Make Up Auto & Manual
TXS 0912C-350	260	7.5	2440	2820	5550	4230	920	3450	125	250	50	50	50
TXS 0912D-400	296	11							150	250	80	50	50
TXS 0912E-450	330	15							150	250	80	50	50
TXS 0912F-500	355	18.5							150	250	80	50	50
TXS 1112E-550	411	15	3050	3430	6470	4230	920	3450	200	300	100	50	50
TXS 1112F-600	443	18.5							200	300	100	50	50
TXS 1112G-650	469	22							200	300	100	50	50
TXS 1112H-700	520	30							200	300	100	50	50
TXS 1112I-750	559	37							200	300	100	50	50
TXS 1212E-600	445	15	3350	3626	6830	4230	920	3450	200	300	100	50	50
TXS 1212F-650	478	18.5							200	300	100	50	50
TXS 1212H-750	564	30							200	300	100	50	50
TXS 1212I-800	607	37							200	300	100	50	50
TXS 1212J-850	648	45							200	300	100	50	50
TXS 1312E-650	492	15	3660	4075	6830	4230	920	3450	200	300	100	50	50
TXS 1312F-700	525	18.5							200	300	100	50	50
TXS 1312G-750	557	22							200	300	100	50	50
TXS 1312H-800	619	30							200	300	100	50	50
TXS 1312I-850	665	37							200	300	100	50	50
TXS 1312J-900	710	45							200	300	100	50	50

Notes: 1. One nominal tonnage represents a 3GPM (0.684 m3/hr) of water from a 95°F (35°C) to 85°F (29.4°C) at a 78°F (25.6°C) entering wet-bulb temperature.

2. If you need multi-cell towers, consult your local Truwater representative.

TX.EE SERIES RANGE



PLAN VIEW



SIDE VIEW



FRONT VIEW

Tower Model	Nominal Tonnage	Motor	Fan diameter	Overall Dimension (mm)					Piping Dimension (mm)				
		kW	(mm)	L	W	H	h	Air Inlet Height K	Water Inlet	Water Outlet	Overflow	Drain	Make Up Auto & Manual
TXS 1316G-900	656	22	3660	4075	6830	5450	920	4670	200	300	100	50	50
TXS 1316H-950	721	30							200	350	100	50	50
TXS 1316I-1000	779	37							200	350	100	50	50
TXS 1316J-1100	830	45							200	350	100	50	50
TXS 1316K-1250	889	55							200	350	100	50	50

Notes: 1. One nominal tonnage represents a 3GPM (0.684 m3/hr) of water from a 95°F (35°C) to 85°F (29.4°C) at a 78°F (25.6°C) entering wet-bulb temperature.

2. If you need multi-cell towers, consult your local Truwater representative.